



Tips

BlackBerry Curve 8350i Smartphone

©2009 Research In Motion Limited. All rights reserved. BlackBerry®, RIM®, Research In Motion®, SureType®, SurePress(TM) and related trademarks, names and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world. Google Mail is a trademark of Google Inc. Hotmail and Windows Live are trademarks of Microsoft Corporation. All other trademarks are the property of their respective owners. This documentation is provided "as is" and without condition, endorsement, guarantee, representation or warranty, or liability of any kind by Research In Motion Limited and its affiliated companies, all of which are expressly disclaimed to the maximum extent permitted by applicable law in your jurisdiction.






MAT-26812-001 Rev. 002 | PRINTSPEC-020 | SWD T405201-620671-0713024355-001 | RCD21IN

Welcome to BlackBerry!









Thank you for choosing a BlackBerry® Curve™ smartphone! To set up your device, complete the following tasks. See the *Getting Started Guide* that came with your device or click **Help** on your device for step-by-step instructions for your device.

- Insert the SIM card
- Insert the battery
- Charge the battery
- Complete the setup wizard







Home screen tips

- To open the application list from the Home screen, press the  key.
- To return to the Home screen, press the  key.
- To lock the keyboard, on the Home screen or in the application list, click **Keyboard Lock**. To unlock the keyboard, press the  key and the  key.
- To unlock the device, type your password. Press the  key.

Typing tips




- To capitalize a letter, hold the letter key until the capitalized letter appears or press the  key and the letter key.
- To type the alternate character on a key, press the  key and the character key. For example, to type a question mark (?), press the  key and the .
- To type a symbol, press the  key. Type the letter that appears below the symbol.
- To type an accented or special character, hold the letter key and roll the trackball to the left or right. Release the letter key when the accented or special character appears. For example, to type ü, hold  and roll the trackball to the left until ü appears.
- To turn on NUM lock, press the  key and the  key.

Message tips






- To compose a message from a message list, press the  key.
- To reply to a message, press the  key.
- To reply to all, press the  key.
- To forward a message, press the  key.
- To move to the top of a message list, press the  key.
- To move to the bottom of a message list, press the  key.

Try this

Copy text in a message and paste it into another application.




1. In a message, place the cursor before the text that you want to copy.
2. Press the  key and roll the trackball.
3. Press the  key.
4. Click **Copy**.
5. Place the cursor where you want to paste the text.
6. Press the  key.
7. Click **Paste**.

Organizer tips






- To search for a contact in a contact list, type the contact name or initials separated by a space.
- To call a highlighted contact or phone number, press the  key.
- To move to the next day, week, or month in the calendar, press the  key.
- To move to the previous day, week, or month in the calendar, press the  key and the  key.
- To change the status of a task in the task list, highlight a task. Press the  key.

Try this

Assign a ring tone to a contact.

1. In the address book, highlight a contact.
2. Press the  key.
3. Click **Edit**.
4. Press the  key.
5. Click **Add Custom Phone Tune**.
6. Set a ring tone.
7. Press the  key.
8. Click **Save**.

Phone tips








- To make a call from the Home screen, type the phone number. Press the  key.
- To end a call, press the  key.
- To answer a call, press the  key.
- To adjust the volume during a call, press the **Volume** keys.
- To turn on or turn off mute during a call, press the  key.
- To turn on or turn off the speakerphone during a call, press the  key.

Make a Push to Talk call

1. Perform one of the following actions:
 - From the Home screen, press the **Push to Talk** key. Click a contact name. Press the **Push to Talk** key.
 - From the Home screen or in the phone application, type part of a contact name. Highlight a contact name or Push to Talk number. Press the **Push to Talk** key.
 - From the Home screen or in the phone application, type a Push to Talk number in the format `<AreaID>*<NetworkID>*<MemberID>`. Press the **Push to Talk** key.
2. Perform any of the following actions:
 - To speak to your contact, press and hold the **Push to Talk** key. Wait for the sound before you speak. Continue to hold the **Push to Talk** key while you speak.
 - To listen to your contact, release the **Push to Talk** key.


To end the call, press the **End** key. If you wait for a short period of time, the call should end automatically.

Browser tips

- To move to a specific web page, press the  key.
- To insert a period (.) in the web address field, press the  key.
- To insert a slash mark (/) in the web address field, press the  key and the  key.
- To add a bookmark, press the  key.
- To open the bookmark list, press the  key.
- To stop loading a web page, press the  key.



Try this

Switch browser views.

1. On a web page, press the  key.
2. Click **Column View** or **Page View**.

Music tips

CAUTION: Do not use your headphones at a high volume. Hearing damage can occur. For more information, see the *Safety and Product Information* booklet, located on the BlackBerry® User Tools CD.








- To pause a song, press the  key.
- To resume playing a song, press the  key again.
- To adjust the volume during a song, press the **Volume** keys.
- To play the next song in a category, press and hold the **Volume Up** key.
- To play the previous song in a category, press and hold the **Volume Down** key.

Try this

Create a playlist.

1. In the media application, click **Music**.
2. Click **Playlists**.
3. Click **New Playlist**.
4. Click **Standard Playlist**.
5. Type a name for the playlist.
6. Press the **Menu** key.
7. Click **Add Songs**.
8. Click a song.
9. To add more songs, repeat steps 6 to 8.
10. Press the **Menu** key.
11. Click **Save**.

Picture tips

- To zoom in to a picture, press the  key.
- To zoom out from a picture, press the  key.
- To zoom to the original picture size, press the  key.
- To fit a picture to the screen size, press the  key.
- To rotate a picture, press the  key.
- To pause a slide show, press the  key.
- To resume a slide show, press the  key again.




Try this

Take a picture.

Depending on your BlackBerry® device, the camera or video camera feature might not be supported.

To take a picture, click the trackball.

Video tips

- To pause a video, press the  key.
- To resume playing a video, press the  key again.
- To restart a video, press the  key.
- To adjust the volume during a video, press the **Volume** keys.

Try this

Record a video.

To perform this task, you might need to have a media card inserted in your BlackBerry® device.

Depending on your BlackBerry device, the camera or video camera feature might not be supported.

1. In the video camera, click the trackball.
2. To pause recording, click the trackball again.